TECHNICAL BROCHURE

EDEN DECKING



FUNCTIONAL LONG LASTING AESTHETIC



EDEN

OUTDOOR




Experience the perfect blend of luxury and durability with EDEN by DEVOX - our latest WPC decking solution, designed for those who demand more from their outdoor spaces.

With a refined aesthetic and superior resilience, EDEN transforms any exterior into an elevated living experience.

NCC Compliant Testing for Slip Rating

Australian Standard	TEAK	IPE
AS4586(A) Wet Pendulum Test	P1	P1
AS4586(B) Dry Floor Friction Test	D1	D0
AS4586(C) Wet Barefoot Inclining Platform Test	B	B






High Durability and Safety

EDEN decking is not only aesthetically pleasing but also highly durable and built to last. Each panel has been rigorously tested for slip resistance, ensuring a safe and secure surface underfoot, making them ideal for installation around pool areas and in gardens where safety is a priority.

Why Choose EDEN by DEVOX?

- Diverse Color Options
- Tested Slip Resistance
- Ease of Installation



EDEN
OUTDOOR


Installation Guide

Eden WPC Decking brings together the beauty of natural timber and the durability of modern engineering. It is the ideal choice for stylish, low-maintenance outdoor living. Whether you're building a backyard or outdoor space. Eden offers a sustainable, slip-resistant solution that looks good year after year.


Tools Needed



Spirit Level



Measuring Tape



Circular Saw




Impact Drill

Accessories



#8-18 x 5/8" CSK
Square Self
Tapper Screws
Zinc Black



Starter Clip



Middle clip



Anti-slip Clip



EDEN
OUTDOOR

Installation Guide

Step 1: Pre-Requisites



A. Inspect all EDEN by DEVOX decking panels for defects or damage



B. Measure the decking area accurately to determine the required number of panels



C. Plan the layout, taking into account any design features or cutouts.



D. Construct a sturdy wooden frame or post to support the decking structure. Ensure the frame is level using the spirit level.



E. Prepare for any necessary cuts for corners or edges using a circular saw.

Step 2: Installing The Starter Board



A. Determine the appropriate spacing and position for the Starter Clips (C-clips) along the frame



B. Screw the Starter Clips (C-clips) securely to the frame at the designated locations.



C. Place the starter board onto the C-clips, ensuring it is aligned and level.



D. Install at least one anti-slip clip per length of the starter board.



E. Make sure the starter board is level using the spirit level.

Step 3: Installing Eden by Devox



A. Position middle clips at regular intervals along the starter board and screw them in place




B. Place the EDEN by DEVOX decking panel onto the middle clips. The clips will automatically provide the appropriate gap between panels.



C. Secure the panels in place, ensuring they are aligned and level.



D. Install at least one anti-slip clip per length of the panel.



E. Check the alignment and levelness of each panel using the spirit level.

DEVOX